Pure skin J

You can download the user manual in Chinese and English from the OR code.

> 您可以从二维码下载 中英文的使用说明书。



电穿孔美眼仪 使用说明书

感谢您购买本产品。为了正确使用本产品,使用前请条必阅 卖此说明书;为了在需要的时候可以随时阅读说明书,请您妥 善保管此说明书。

关于本说明书:

本说明书所示产品图片及相关产品特征介绍,以及一些 名词的解释,仅可作参考,用户使用时以实物为准,所引用 的数据来自本公司实验室。

一、安全注意事项

使用前请 务必阅读安全注意事项。 请按照说明书内容及建议正确使用本产品。

产品使用后应及时清洁以避免油脂及其残余物的积聚。

○ 危险 错误操作会导致人身伤害的相关内容

▲ 注意 错误操作会导致人身安全或财产损失的相关内容

○危险

- 请使用本产品随机配送的充电线和符合产品规格要求的充电 器来充电,并正确将充电器插头与家用插座连接,以避免导 致故障, 起火或因发执而引起火灾,
- 由于本产品内置可充电电池,请勿将本产品置入火中或在高 温、高热的环境中使用,这可能会导致故障、起火或因发热 而引起火灾。
- 如果产品发生变形、破损或有异味,请勿再使用,以避免发 生触电和火灾的危险。

↑ 注意

- 为了避免危险发生,请勿与医疗用电子仪器同时使用。
- 做过心脏手术或携带心脏起搏器、埋入式除颤器等医疗用电 子仪器的人严禁使用。
- 初次使用或是敏感性肌肤者,请先小面积肌肤试用,确认肌 肤状况后再使用。

如果产品损坏,为了避免危险,必须由制造商的维修部或类

- 请勿在易燃易爆物品附近使用本产品(如酒精、汽油、喷雾 剂等),可能导致火灾或爆炸。
- 要将包装材料如塑料袋放置于儿童不能触及的地方。 • 清洁和保养前,请先关机断电。
- 请勿将本产品使用于本说明书规定以外的用途,以免导致故 障或因发热而引起火灾。
- 使用时,如产品异常发热,请立即停止使用并关机。
- 产品故障时请不要使用,在故障状态使用本产品有可能对身 体产生不良影响或其它危险。 请不要在同一部位连续使用本产品、否则可能产生灼热感。
- 本产品不适用于身体、感官或精神有问题者或缺乏经验与常 识者(包括儿童)使用、除非有监护者监督并对产品的使用加
- 以指导,且对使用者的安全能承担责任。 请勿将本产品浸入水中或用水龙头直接冲洗。如感觉皮肤或身体出现不适,请立即停止使用。
- 请不要在潮湿的环境存放本产品
- 使用时,请取下贵金属物件以及手表等。
- 孕期、育后哺乳期或经期妇女。
- -过敏症人群,有皮肤病、皮肤炎症、皮肤过敏、其它皮肤 疾病以及严重腑伤者。
- -有皮肤损伤、湿疹、肿胀等情况的人群。 -刚做完手术,正在恢复的人群。
- -因骨折或是整形面在脸部、或是体内接受过金属,硅聚合 物、塑料埋入手术者。 -患有心脏疾病,恶性肿瘤,癫痫,糖尿病,传染病,急性
- ---长期使用类固醇类荷尔蒙药剂或者肝功能障碍引起毛细血
- -过去3个月内,在使用部位进行过外科手术,激光祛皱, 深层化学剥脱术的人群。

二、介绍

这是一款集合EMS微电流、RF射频及LED红光于一体的 综合性家用眼部护理产品。(特定的90KHz电流通过电极作用

使用时,请结合美容凝胶和眼霜等有一定粘稠度的护肤产 品进行护理, 可实现科学高效的美肤效果。



※长按1秒开机,默认为1档,按第二次为2档,按第三次 为3档,长按1秒关机。 ※首次使用、建议从1档开始使用。

四、操作说明

[奈申]

- 首次使用,请先将产品充满电后再使用。
- 将产品连接上USB充电线、充电器,并插入家用电源插座;
 充电中,充电指示灯闪烁红光;
- 充电时间大约需要2.5小时。 充电中- 公- 红光闪 充满电- 绿光亮





使用前请卸妆及洁面



◆淡化眼纹◆

在眼部涂抹适量的美容凝胶或眼霜等有 一定粘稠度的护肤产品。开机后用探头 充分接触皮肤,力度适中。探头顺着眼 绞走向的垂直方向,缓缓提拉约1厘米后 ,在此处停留约3−5秒,待眼纹拉伸紧 固。重复5次、重做下一个部位。

摘除書金属



在眼部涂抹适量的美容凝胶或眼霜等有

一定粘稠度的护肤产品。 开机后,一只手握住仪器,让探头充分 中。探头从下到上、缓缓提拉约2-3厘 米后,在此处停留2-3秒。重复5-6次, 帮助强化紧致眼角轮廓。使用中需保持

◆改善黑眼圈眼袋◆

◆提拉紧塑眼角◆

在眼部涂抹适量的美容凝胶或眼霜等有 一定粘稠度的护肤产品。 开机后,手握住机器用探头轻轻按摩黑 一定粘稠(kpt)// (m.)
开机后,手握住机能用探头轻轻按摩無限圈和眼袋部位,力度适中,动作舒缓,遵循从眼内角往眼外角移动的原则。

◆眼霜精华导入◆

将眼霜及适量的精华涂抹在眼部周围, 并用手指均匀扩散到肌肤。开机,用探 头轻轻按摩涂抹过产品的眼部肌肤,力 度适中,动作舒缓,遵循从内往外,从 下往上的移动原则。如此重复5-6次。

【 关机 】 护理完成后,长按开机键1秒关机。

- 护理例开始进行时,肌肤可能感觉不到明显的热度,做了几分钟后 就会开始慢慢由内而外发热。护理过程中可能会感觉到皮肤发热或轻微刺痛,部分使用者在使用
- 后还可能会感觉到皮肤有轻微发红,这些均属正常现象,通常在使 用后数分钟内消失,如果在使用中感觉到皮肤异常发热,建议停止

五、清洁维护和保养

- 清洁前,请先关机。
- 本产品不防水,切勿将本器具浸入水中或用水龙头直接冲洗。 不要使用钢丝球、研磨性清洁剂或腐蚀性液体(如汽油或丙
- 酮)或化学器来清洁本产品。 • 可以使用柔软的湿布或医用酒精来清洁并用柔软干燥的布来
- 擦拭干净.
- 长期不使用(2个月以上),请每间隔二个月将产品拿出 来充满电后再存放。

六、存放

- 使用后,请倒干净储液盒的护理液并清洁干净后再存放。
- 可以将产品存放干旅行袋中。 • 请保管在孩子够不着的地方。
- 请保管在湿气和灰尘少的地方 • 请避免将产品存放于高温或阳光直射的地方。

注意:不要将潮湿的产品放在袋中。

使用操作时如出现故障,请进行以下检查。如果无法排除故障 或本产品仍无法理想操作,请直接联系总公司客服部门,请勿 自行拆卸及尝试维修。

• 本产品只适用于个人家庭护理使用,不适合商业用途。

• 我们为产品提供为期1年的保修、保修期从购买日开始计算

- 由于使用不当造成的损坏,例如:使用错误的电源、将产

品插入不合适的插座、人为损坏等。 - 正常使用引起的产品老化、磨损,但对产品的使用功能影

- 用于其它用途,或操作不当或非专业维修或者使用非本公

- 因不可抗力因素(如雷电、地震、火灾、水灾等)造成的

	现象	可能原因	措施
	使用中突然关机 或不能开机	电池没充满电	将主机充满电再使用
	充电时,充电指 示灯不亮	主机、充电器、 插头没连接好	重新连接好主机和充电器,或将列 电器插于另一个家用插座上使用
		电池进入休眠状态	电池需要充电6-30分钟的苏醒时间,属于正常现象,需充满电再使用
	按摩头接触肌肤 无刺激感或感觉 不到热度	肌肤过于干燥	请在护理部位均匀的涂抹美容凝版 或眼霜等有一定粘稠度的护肤产品 再使用

九、废物处理

- 寿命结束时,不能被当作一般家庭废物处理。 请咨询当地政府,根据废物的分类进行回收处理。
- 此器且内部装有锂电池, 所以: -在废弃器具前,必须将电池从器具中取出;
- -在取出电池时,器具必须要关机断电;
- -电池应安全地处置;
- -用户不能自行更换电池。建议您将产品送到 官方收集点,让专业人员移除电池。
- 取出电池步骤: 当您使用工具打开产品时以及您在弃置电
- 池时,请采取必要的安全保护措施。
- -将产品前盖用工具撬开;

-- 拧开PCB板上的螺丝,取下PCB板; -- 拔出电池引线,取下电池。

十、规格参数

净 重: 约78.3克 产品名称: Pure skin J

工作电压: 3.7V== 800mAh 额定功率: 5.0W 充电电源: 5V==1A

在本产品或使用说明书或包装上的此标示。指示此产品在使用

产品尺寸: 28.5* 8.0*165.5mm

执行标准: GB 4706 1 GB 4706 15

装箱清单: 主机1台, USB充电线1根, 用说明书1份。

Thank you for purchasing this product! In order to use this product correctly, please read this manual before use; in order to read the manual at any time when you need it, please keep this manual in a safe place.

manual, as well as some nouns, can only be used as a reference The user will use the actual product as the standard, and the eferenced data comes from the company's laboratory.

About this manual:

Safety Precautions Be sure to read the safety precautions before use.
Please use this product correctly according to the contents and recommendations of the manual.

The product should be cleaned in time after use to avoid accumulation of grease and its residues.

Related content:Incorrect actions can lead to Danger personal injury
Related content:Incorrect operation can Caution result in personal safety or property damage

○ Danger

- Please use the charging cable supplied with this product or the charging cable that meets the product specifications, and connect the charger plug to the household socket correctly to avoid malfunction or fire caused by heat.
 Since this product has a built-in rechargeable battery, do not put it in a fire or use it in a high temperature environment which may cause malfunction or fire due to heat.
 If the product is unusually hot or deformed, damaged, or smelly, do not use it to avoid the risk of electric shock and fire.

⚠ Caution

- To prevent the occurrence of danger, do not use it with
- To prevent the occurrence of danger, do not use it will medical electronic equipment.
 It is strictly forbidden to use a person who has undergone cardiac surgery or a medical electronic device such as a pacemaker or an embedded defibrillator placed inside the For first-time use or sensitive skin, please try a small area of

- If the machine is damaged, in order to avoid danger, it must be repaired by the manufacturer, its maintenance department or a specialist in a similar department.
 Do not use this product (such as alcohol, benzine, spray, etc.) near flammable or explosive materials, which may result in fire
- Place packaging materials such as plastic bags where children
- Please turn off the power before cleaning and maintenance.
- Do not use this product for purposes other than those specified in this manual to avoid malfunction or fire due to heat. When using, if the product is abnormally hot, please stop using it immediately and shut it down.

 Do not use the machine if it is faulty. Using this product in a
- faulty state may have adverse effects on the body or other
- Please do not use this product continuously in the same area. otherwise it may cause a burning sensation.


 This product is not intended for use by persons with physical, sensory or mental problems, or those who lack experience
- and knowledge (including children), unless supervised by a guardian and instructed in the use of the product, and
- Do not immerse the appliance in water or rinse it directly with


- If you feel any discomfort in your skin or body, stop using it immediately.
 Please do not store this product in a humid environment.
 When using, remove precious metal objects and watches.
 Do not use this product in the following situations:
 —During pregnancy, leatating or menstruating women.
 —Allergic people have skin diseases, skin inflammation, skin irritation, other skin diseases and severe sunburn.
 —People with skin damage, wetness, swelling, etc.
 —The person who has just finished surgery and is recovering.
 —Due to the upper fracture or the plastic face, the metal has been received on the face or in the body, and the silicon polymer is embedded in the surgery.
 —People with heart disease, malignant tumors, epilepsy, diabetes, infectious diseases, acute conditions.
 —Long-term use of steroid hormone drugs or liver dysfunction caused by capillary vasodilatation.
 —In the past 3 months, surgery has been performed at the site of use, with long-lasting laser or deep chemical stripping.

Introduction This is a comprehensive personal skin care EMS RF Eye Device that combines EMS micro-current (RF) and led

When used it can be combined with skin care products such as cream or essence to achieve a scientific and efficient skin-beautifying effect.


Part Identification






Turn on/off: Press and turn on the power button for 1 second *Intensity selection: The default is 1 for the power on, Each

How to Use



[Charging]
For the first time, please fully charge the machine before u



 Connect the machine to the charging cable and charger, and plug into the household power socket; During charging, the charging indicator flashes re When fully charged, the charging indicator



Preparation before Use 1

◆Lightening eyelines◆







◆Lifting and shaping of eye corners◆

Apply a proper amount of eye cream or beauty gel. Turn on the device. beauty gel. Turn on the device.
Hold the instrument in one hand and
allow the probe to fully contact and press
the outer corner of the eye 1 cm below the
center. The probe is lifted from bottom to
top, slowly pulling about 2 - 3 cm, and
staying here for 2-3 seconds. Repeat 5-6
limpt to held in behalf the corner of the outer.

times to help tighten the corner of the eyes. Keep your movements comfortable during use

Apply a proper amount of eye cream or Apply a proper amount of eye cream or beauty gel. Turn on the device. Holding the machine with your hand. Gently massage the dark circles and eye bags with the probe. The force is moderate, the movement is soothing, and the principle of moving from the inner corner to the outer corner of the eye is followed. Repeat 8-10 times as appropriate.

[Power Off]

◆Introduction of eye essence◆

After the care is completed, press and hold the power button for 1 second to turn off.

. When the care was first started, the skin did not fee

When the care was first started, the skin did not feel
the obvious heat. After a few minutes, began to feeling
it from the inside out slowly.
 During the nursing process, the skin may feel hot or
slight pain. Some users may feel a slight redness after
using the skin. This phenomenon usually disappears
within a few minutes after use. If the skin feels abnor
mally hot during use, it is recommended to stop using
and let the skin cool down first.

- Cleaning and maintenance
- Before cleaning, please turn off the device. This product is not waterproof. Do not soak the appliance in water or flush it directly with faucet. . Do not use steel wire brush, abrasive cleaner or corrosive liquid
- . You can clean with a soft wet cloth or medical alcohol and wipe If it is not used for a long time (more than 2 months), please take the product out every two months and store it after it is fully

- Storage • After use, please pour the lotion from the storage box and
- clean it before storing. The product can be stored in a travel bag.
- Please keep it out of the children's reach. • Please keep it in a place with little moisture and dust. • Please avoid storing the product in a place with high

Note: Do not put a humid product in the bag.

temperature or direct sunlight.

After-sales

6

- This appliance is intended for personal use only and is not suitable for commercial use.

 We offer a one-year warranty on the product, which is calculated from the date of purchase.

 The company does not guarantee the following conditions:

 Damage caused by improper use, such as using the wrong power supply, inserting the product into an improper socket,
- man-made damage, etc. The product caused by normal use is aging and wear, but it has little effect on the function of the product
- Damage caused by force majeure factors (such as lightning, earthquakes, fires, floods, etc.).

Fault analysis and elimination

In case of any malfunction during the operation, please carry out following inspections. If failures cannot be eliminated or the product cannot operate properly, please contact Kingdom's after-sales service center. Do not disassemble and attempt to repair it by vourself.

Situation	Possible Reason	Measure
Sudden shutdow or machine does not start	The battery is not fully charged	Fully charge the host and use it again
Charging light is not lit	charging stand.	Reconnect the main unit and charge or plug the charger into another household socket.
	Battery is dormant	The battery needs 6-30 minutes bact to working. It is a normal phenomeno and needs to be fully charged before use.
Massage head contact with skin without irritation or feeling of heat.	The skin is too dry	Please apply the lotion to your skir before use

七、售后维修

以下情况公司不保修:

八、故障分析及排除

司的配件而导致的产品问题。
- 易耗品、附赠配件等耗材配件。

Before the appliance is discarded, the battery must be take

and turned off; The battery shall be disposed of safely;

-Unscrew the PCB board and remove the PCB board: -Unplug the battery leads and remove the battery.

The marking on this product or packaging material or accessory indicates that the material is made from a recyclable material. Separate waste into different ecycling levels to facilitate the recycling of usefu

The user cannot change the battery by himself.
It is recommended that you send the product
to the official collection point so that the
professional removes the battery.

-Pry the front cover of the product with a tool;

Product Name: Pure skin J Voltage:3.7V == 800mAh Rated Power: 5.0W Charging Power Supply: 5V=1A
Product Dimensions: 0.7 Packing List: 1 main unit, 1 charging cable,

his appliance is equipped with lithium battery inside, so:

When the battery is taken out, the appliance must be shut down

professional removes the battery:
Steps to remove the battery:

Specification

1 operation manual