Water peeling II

Clean pores Nutrition introduction

INSTRUCTION ▶


Cleansing mode

Moisturizing mode

INSTRUCTION ▶

GHARGING ▶

1.Long press 2s power button to power on Figure 1



Hold the conductive strips on both sides to cleasing face with positive ion. It is recommended to use cleanser first before cleansing the face.

3. Apply the skin care products to the face Figure 2 4.As shown in Figure 2, to face lifting

1.Long press 2s power button to power on Figure

Hold the conductive strips on both sides and enter the negative ion mode

It is recommended to use a mask first, before using Moisturizing mode to

3. Apply the skin care products to the face

4. As shown in Figure 2, to face lifting

2.Press twice to select Moisturizing mode

Moisturizing import mode with color light function



repair mode

1.Long press 2s power button to power on 2.Press three times to select repair mode Face **repair** with color light function.

It is recommended to use with Essential oil for better effect

3.Apply the skin care products to the face 4.As shown in Figure 2, to face lifting



Please charge before use. 2.Plug to the cell phone adapter, power bank or computer USB

The LED light flashes continuously during charging, and the LED light is keep turn on when it is fully charged.

1.USB charging cable to connect USB interface Please know the product is arrived without fully charged.

Please confirm the status of the lithium battery before charging. Before using for the first time, please remove the sealing film of the skin.







CHARGING PRECAUTIONS ▶

When the battery is low, product will emit a "beep" sound, and then turn off. Note that the remaining amount of the battery is insufficient. Please charge the product immediately.

It cost about 2.5-3 hour to be fully charged.

1. Make sure that the unit's power is off.

MAINTENANCE AND STORAGE ▶

2. Use a wet tissue or alcohol on the machine head to carefully wiping.

Do not wipe this product with corrosive chemical industrial products such as thinner solvents.

3. After clean the machine head, place it in a dry area to safekeeping. Do not store in a damp place such as a bathroom.

Do not store in a place where children can touch it.

-2-

Manual >

STRUCTURE ▶

Metal head

Cleansing mode

Moisturizing mode repairmode

Power switch - Mode selection button

Ion conductive strip

USB charging interface-

1. Deep cleansing and removing dead skin. 2. Fade pigmentation spots.

FUNCTION >

- 3. Anti-wrinkle, enhance skin elasticity.
- 4. Promote blood circulation and lymph fluid metabolism.
- 5. Enhance the regeneration ability and permeability of skin cells.
- 6. face massage, nutrient import, variegated export.

PRODUCT PARAMETERS ▶

Power: ≤3W Instrument net weight: 122g Size: 172*54*26mm Working time: 15 minutes

Battery: 500mA Use time: about a week

Ultrasound is a high-frequency mechanical vibration wave that is widely used in medical and osmetic fields. The Mechanical waves have mechanical action, warming action and catalysis, which can be used in low-energy high-frequency vibration. The ultrasonic can production a gentle resonance

PRODUCT FEATURES ▶

Ultrasonic skin scrubber uses Ultrasonic technology which freguncy are more than 20,000 times per second. The vibration causes intense friction between the molecules, which can penetrate deep vibration into the skin and make the molecules sharply Friction, deep temperature rise, cell metabolism is strong, micro circulation is accelerated, and metabolite reflux is promoted. Through The conversion of the ion stream the permeability of the cell membrane is enhanced and the semi-permeable nembrane produces an intracellular slurry microfluid.The fatty acid is catabolized into a fine volume of CO2 and H2O fat. At the same time, it is matched work with some skin care products, beauty effects are more significant.

with skin that enhances cell viability and interstitial tissue Permeability, dredge sweat glands, shrink

Ultrasonic skin scrubber through high-frequency vibration to improve microcirculation during fat. movement, burning and cleavaging the fat cells which converted into metabolites and excreted to achieve deep cleansing. Pick with a special shovel type probe, making ultrasonic vibration, effectively enter under skin 4-7 mm to deep cleansing. The liquid becomes finer and atomized, and these dirt and excess sebum can be emulsified to block in the pores if without cleansing. Under ultrasonic vibration, the cosmetic residue, emulsified dirt, and with the splash of water splashing, this cleaning effect is faster and more effective. This is like an ultrasonic cleaner that cleans precision machinery. This phenomenon is also will happen to the skin Thereby removing the stratum comeum fat granules imples, etc., so that your skin care products are no longer wasted, allowing the skin to absorb better

WARRANTY CARD ▶

- 1. Free maintain for the breakdown caused by product quality problems.
- 2. One year guarantee from the date of purchase.
- 3. Free to change broken parts, freight is collected by customers.
- 4. If breakdown caused by the force majeure, free maintainwon't be given and freight shall be collected by customers.
- 5. Please fill the guarantee clearly, without any revision. Please take good care ofguarantee. If lost, won't be re-provided.

保証書				
品名	Water peeling ${ m I\hspace{1em}I}$			
お名前				
ご住所 〒				
TEL				
ご購入日	年	月	H	
保証期間/ご購入日より1年間				
販売店印				
発売元 株式会社 工力	 プァンジール	レ 製造販売	元 株式会社 ア	グレックス

■本社 ₹321-0164 ₹261-0023

栃木県宇都宮市双葉 1-13-50 千葉県千葉市美浜区中瀬 1-3 MTG B 棟 9F TEL 0120-169-119 TEL 043-350-0111 FAX 043-350-0114

-7-

Input voltage: DC 5V Silicone cleansing brush

Name: Water peeling II

Charging time: about 3H

-5-

0