

05

07

08

Warranty card

Please fill in the following information so as to enjoy better service

Warranty period	One year since the date of purchasing	Arrival date of product: DD MM YY
Customer information	Customer address:	
	Customer name:	
	Tel:	
Maintenance reason		

Troubleshooting

Fault	Possible reason	Measures
Shovel doesn't vibrate.	Shovel deformation	Hold the shovel with both hands and correct it
	Internal wire falls off	Please contact after-sale department of our factory
	Reduce the operation force, just touch the shovel gently	Reduce the operation force, just touch the shovel
Fail to start	Battery power shortage	Charge the machine for 2h prior to power on
	Battery damage caused by too long resting period of the machine	Please contact after-sale department of our factory
	Damage caused by water entering machine	Please contact after-sale department of our factory
	Failure caused by water entering the key	Please contact after-sale department of our factory
Ion function failure	Hands don't touch the bus bar on the lateral side of machine	During operation, the hands should touch the bus bar on the lateral side of machine
	Internal circuit of machine is damaged owing to water ingress	Please contact after-sale department of our factory
If the product cannot work normally, please stop using it and contact after-sale department of the factory.		

Aer-sale guarantee and service

The instrument is only used for personal care, rather than professional purpose. We only provide one-year warranty for the product, and the warranty period commences from the purchasing date. For product defects owing to material or production process within warranty period, we may replace the parts or the whole product according to the specific condition. When applying for maintenance, please submit the product and purchasing receipt (purchasing invoice) indicating purchasing date to the authorized Zhuochen Maintenance Station or after-sale department of our factory. We are not liable for the warranty in the following cases: Damage owing to improper use, for example, use wrong power, insert the product to inappropriate socket, human-made damage, etc. Product aging and wear owing to normal use, which doesn't affect the normal purpose of product. The product is used for other purposes, or product problems caused by improper operation, non-professional maintenance or using accessories not provided by our company. Services don't include damage caused by the above behaviors.

Environmental protection

The product, package material and accessories are made of recyclable materials. The recycling grade of waste is good for recycling of useful materials.

Waste treatment

The mark on the product, instruction book or package reminds that the product cannot be treated as ordinary domestic waste when the service life comes to an end. Please consult local government and recycle the product according to the waste classification.

Technical parameters

Product Number: 7C-CPY-01  
Package Dimensions: 205\*75\*40mm  
Product Weight: 76g  
Battery Voltage: 3.7v  
Rated Frequency: 1.5w  
Battery Capacity: 500ma  
Blade Frequency: 24k±1k

Not Suitable For The Crowd: Pregnant And Menstruating Women, Allergic People, People With Skin Damage

BEAUTY SPATULA

Ultrasonic Ion Cleaner

Cleaning Scrubber

Description book

Please read the instruction book carefully prior to use.

01

02

03

04

05

Safety precautions

Thank you for purchasing C-105 ultrasonic ion cleansing instrument. Please read the instruction book carefully prior to use the product, and keep it properly so as to hand it over to any subsequent users.

About the instruction book: the product picture shown and related product feature introduction and the interpretation of some terms in the instruction book are only for reference. They are subject to the real product.

Safety precautions

The instruction book contains safety instructions of proper use of the product. Therefore, please read the it carefully and keep it properly to avoid damage and danger caused by improper use. The product is personal product and it cannot be used for many people in an organization. All the safety instructions are for your safety.

**Notes:**

Such grade of mark indicates possible danger. It may cause personal injury or property loss in serious case. To this end, please comply with the corresponding warning description.

- If the charging line is damaged, please use the same specification of charging line to substitute it or contact after-sale department of our factory.
- If you feel ache or abnormal on the skin or your body, please stop using it immediately.
- When cleaning and maintaining the instrument, please close the machine and pull out the plug and do it in a shutdown state.
- Children are forbidden to use the product.
- Please don't use the product nearby flammable materials (alcohol, gasoline, nail polish remover, spray, etc.)
- Please don't immerse the product in the water or flush the product with tap water directly.
- If the product is damaged owing to careless drop or collision, please don't use it again.
- Please don't dismantle or repair the product arbitrarily. Please contact the shop where you purchase the product for maintenance.
- Please use the charging line provided by our factory to ensure the voltage conform to the product specification requirements.
- The instrument must be cleaned in time after use to avoid accumulation of grease or other remnants.
- The products are forbidden to be used in the case of bath or shower. Please don't use the product nearby bathtub full of water, water basin or other vessels.

The following people are unsuitable to use the product

- Female in the pregnancy or menstruation period, or one with skin problem owing to hormone imbalance
- Allergic population, person with skin disease, dermatitis, skin allergy and serious sunburn
- Population with skin damage, eczema and swelling
- Population during restoration after operation
- Persons who have deficiencies in limbs, sense, or spirit, or lack experience is forbidden to use the product unless under the supervision and guidance of guardian and the guardian is liable for the safety of user.

Brief Introduction

If the skin is not thoroughly cleaned, even if the product is good, it cannot be absorbed by the skin. Such situation lasts long and the skin will lose sense of transparency. Moreover, pimple, slack, black spot, and other skin problems will appear gradually.

Ultrasonic ion cleansing instrument cares the skin through high-frequency 55 shovel of circuit owing to ion import and export.

Feature

1. Ultrasonic wave vibration, ionic impurities export, skin cleaning.
2. Pat for massage, ionic current nutrition import.

Name of parts

USB charging line

Dust cover

Switch (function shift key)

Ionic induction bar

Use instruction

**Preparation prior to use**

1. For the first use, please charge the machine for 2h.
2. Press and hold the key for 2 seconds, turn it on or off, and press the key to switch the function.
3. Clean the shovel of machine with a piece of clean cloth or cotton pad.
4. Apply the cleanser solution or clean water to the skin.
5. When there is no power, automatically turn off after the two drops sounds. When charging, the lights are lit one by one, fully-charged, and the lights are all on.

**Skin cleaning**

Wash the face with clean water and apply facial cleanser

Press one gear to shift ultrasonic mode

Hold the machine and move the shovel slowly along the position to be cleaned, as shown in Figure 1 (put the buckling position downward, against the direction of pore)

**Deep export**

Clean face with clean water, steam face with hot-spray facial vaporizer for 5m (or apply warm towel to the face for 5m).

Apply this head remover lotion (for 10m)

Press 4th gear to shift into positive ion export mode.

Hold the machine and move the shovel slowly along the position to be cleaned, as shown in Figure 2 (put the buckling position downward, against the direction of pore)

Use the product for 10m and then clean it with clean water.

**Nutrition import**

Clean face with clean water, steam face with hot-spray facial vaporizer for 5m (or apply warm towel to the face for 5m). Apply nutrition essence

Press 3rd gear to shift into fast negative ion import mode from bottom to top, as shown in Figure 3, move slowly along the pore direction for 5m.

Press 2nd gear to shift into slow patting import mode from bottom to top, as shown in Figure 4, move slowly along the pore direction for 5m.

Clean the face with clean water, and steam face with cold-spray facial vaporizer for 10m to shrink pore (converge skin)

Deep and effective constituents promote metabolism and makes

Powerful fluctuation of ultrasonic wave activates the skin

Cleaning operation procedures

Face cleaning and care

Forehead and mandible cleaning and care

Nose bridge cleaning and care

**Warm tip**

- When using the product, please hold the bus bar on the lateral side of machine, then the ion import and export function can be realized normally.
- When using the product, the shovel angle (about 45 degrees) shall be shown in the figure and pushed ahead against the pore direction.
- When using the product, please don't make the product stop, please move it slowly.
- If the face has inflammation, please use it after the inflammation disappears.
- The product is suggested to use for twice-three times/week, please don't use it for many times a day.
- Prior to operation, the shovel and machine shall be cleaned.

Cleaning and maintenance

- Please keep the product away from humidity, and don't put the instrument in the dish-washing machine or microwave oven. Prior to cleaning, please close the machine.
- Please don't use sharp, corrosive, or volatile diluents.
- The product can be wiped gently with cold water or warm water or soft cloth or cotton pad.
- Please don't flush the instrument with water directly, because it may damage the machine.
- If the machine keeps idle for a long time (about three months), please fully charge the machine and then store the machine for fear of machine damage owing to battery power deficiency.